

# R-36DTF Veritek<sup>®</sup> Double Threshold Shower Floors With Fit-Flo<sup>™</sup> Drain

### Manufactured from Veritek®

(See page 2 for detailed information.)

WARRANTY Limited Lifetime – Residential Limited 5-year – Commercial

18"

77/-"

### FEATURES

- Will not mold or mildew, no grout to clean.
- Coordinates with other Swanstone or Veritek® products.
- Pebbled, slip-resistant surface.

Nominal

• Made of Veritek<sup>®</sup> with no surface coating to chip or crack.

	¥ <sup>-716</sup>		
36" 	3" dia.	17 <sup>13</sup> /16 <sup>4</sup>	↑ 18" ↓
	←3	6"───►	

1 37.....



# Model Size 36" 36" 18" 18" R-36DTF 36" x 36" 36-1/16" 36-1/16" 18-3/16" 18-3/16"

IMPORTANT: Rough-in dimensions are provided for reference only. You must measure the actual shower floor and check local building code requirements before construction of the stud wall.

## SPECIFICATIONS

R-36DTF Veritek <sup>®</sup>	Double	Threshold	Shower	Floors	With	Fit-FloTM	Drain
K- JODIF Ventek	Double	Thesholu	JIIUwei	FLUUIS	VVIUI	FIL-FIO · ···	Dialli

.....

Model	Part	Nominal Size Dimensions		- · · · P	Carton Dims. In.	Cu. Ft.
R-36DTF	FD03636MD	36" D x 36" W (914 mm x 914 mm)	44	-	42 X 41 X 10	10

**Rough-In Dimensions** 

Includes: One code-approved compression-molded Veritek<sup>®</sup> shower floor with molded-in Fit-Flo drain.

Packaging: Each floor packed in a rectangular carton.

# COLORS

- Solid Colors:
- White (010)Bisque (018)
- Bone (037)
- Done (057)

# STANDARDS AND RATINGS

American National Standard Institute—ANSI Z124.1.2 International Association of Plumbing and Mechanical Officials (IAPMO)—Listed CSA Standard B45.5 by IAPMO Uniform Plumbing Code (UPC)

For a complete list of tests and results see the Technical Data Sheet.

## SUPPORT DOCUMENTS

Installation instructions available at **swanstone.com**.

#### MAINTENANCE AND CLEANING INFORMATION

Clean regularly with common household liquid cleaners and a sponge or soft cloth. For hard water stains, scale removers can be used. If necessary, abrasive cleaners can be used with a nylon brush or pad to remove build up on the shower floor surface. **Do not** use a metalscouring pad or a wire brush, as it will damage the surface. **Do not** use "leave on" cleaning products, such as automatic spray shower cleaners. Prolonged contact with harsh chemicals could have an adverse reaction over time and discolor surfaces. **Do not** use cleaning agents that caution use on acrylic, polyester or plastics.

MADE IN USA